5,Simplex

UL, ULC, CSFM Listed; FM Approved*

Features

Compatible with Simplex 4120 Network Converts multiple 4120 network communications signals into a single fiber optic link to:

- Multiplex audio signals (analog and/or digital) AND digital communications into full-duplex transmission over a single fiber optic cable
- Communicate from a Fire Alarm Control Panel to a Transponder, or provide 4120 Network communications
- Provide 4120 Network communication support for Ring, Hub, and Star Topologies, and their combinations, by performing the function of a Physical Bridge without slowing data rates

Laser optical transmitters provide:

- Increased transmission distances compared to copper wiring (over 20 miles (32 km) may be possible with low-loss single-mode fiber)
- Designs are optimized for fiber type; select models for single mode fiber, or models for multi-mode fiber
 Enhanced Analog Audio (EAA) feature:
- Provides a decoded analog audio signal at the receiving modem for local use; AND also provides the original digitally encoded signal for connection to the next modem in the communications link
- With EAA, total system distance is essentially unlimited

Communication combinations include:

- Digital Audio Riser + Analog Audio Riser #2 + 4120 Network Communications
- Digital Audio Riser + Analog Audio Riser #2 + RUI (Remote Unit Interface) Communications
- Both Analog Audio Risers + 4120 Network Communications
- Both Analog Audio Risers + RUI Communications
- Or, any of the signals individually; refer to application references on pages 4 and 6 for more details


Panel mounted applications:

- Standard two-Slot module for 4100ES and 4100U Fire Alarm Control Panel or 4100ES/4100U MINIPLEX Transponder mounting
- A separate mounting plate is available for 4100/4120 panel mount or utility cabinet mounting.
- Note: 4120 Network Fiber Modems communicate in pairs; a Left-Port Modem only communicates with a Right-Port Modem

Fiber Modem remote cabinet mounting:

- Available in beige or red; includes a Left-Port Fiber Modem; space is provided for a Right-Port Fiber Modem (ordered separately)
- Compatible with Simplex[®] control panel model Series 4100ES, 4100U, 4010ES, 4010, 4007ES, 4190 Series TrueSite Workstation, RUI and RUI+ compatible equipment, and legacy 4100/4100+/4120

Multiple Signal Fiber Optic Modems and Accessories for 4120 Network



4100ES System Reference with Audio & Data Fiber Modems

Features (Continued)

Optional Audio Expansion Modules:

• Provide an interface to 25 VRMS and 70.7 VRMS audio levels from 4100/4120 fire alarm control panels

Description

Multiple Signal Fiber Optic Modems combine multiple system communications signals and converts them to fiber optic communications for transmission via a single, full duplex fiber optic cable connection that simplifies field wiring and increases transmission distances. Communications can be sent individually or combined.

Additional Information. For additional application information, refer to 4120 Network Products and Specifications data sheet S4100-0056 and Fiber Optic Modem Installation Instructions 579-831.

Fire Control Panels

^{*} This product has been approved by the California State Fire Marshal (CSFM) pursuant to Section 13144.1 of the California Health and Safety Code. See CSFM Listing 7165-0026:251 for allowable values and/or conditions concerning material presented in this document. It is subject to re-examination, revision, and possible cancellation. MEA (NYC) Approvals are not applicable for this product category. Additional listings may be applicable; contact your local Simplex product supplier for the latest status. Listings and approvals under Simplex Time Recorder Co. are the property of Tyco Fire Protection Products.

Operation

Bi-Directional Communications. Fiber optic communications are accomplished by transmitting and receiving over two different light wavelengths (refer to diagram on page 3). In order to complete a fiber optic link, complementary receive/transmit modem pairs are required. The two required modem versions are identified as Left-Port Modems and Right-Port Modems (refer to list below for model numbers). One of each is required to complete the fiber optic communications link. ("Right" and "Left" are designated for reference purposes only and do not refer to actual physical locations.)

Multiple Connections. Each modem has field wiring connections for the Digital Audio Riser, Analog Audio Risers, RUI, and 4120 Network communications (see page 5 for terminal reference information). Configurations are determined by on-board switch and jumper selections. Modem operation is essentially transparent to the connected equipment. However, Fiber Modems are entered into the system programmer for current calculations and mounting allocations.

Fiber Modem Terms

Enhanced Analog Audio. (For systems only using one Analog Audio Riser). At the Head-End audio control panel, the Riser 1 analog audio signal is digitally encoded and transmitted via fiber optics to the receiving Fiber Modem. At the receiving modem, the digital signal is decoded back to analog for local use, but when selected for Enhanced Analog Audio (EAA), the digitized signal is also available, routed to the DAR (Digital Audio Riser) terminals. It can then be **wired** to the next Fiber Modem in the communications link without requiring additional signal conversion. (**Note:** The next modem in the link must be in the same cabinet or in a close-nippled cabinet.) With EAA, Riser 1 distances are limited to system distances; **without EAA**, Riser 1 signals can be passed through a **maximum of six (6)** Fiber Modem pairs which is also the limit for systems using both Analog Audio Risers 1 and 2. (DAR connections for digital audio are not available since those terminals are used for EAA.) Refer to the diagram on page 3 for more detail.

Generic Modem. Fiber Modems in a stand-alone system or in a 4120 Network loop have specific functions and internal settings depending on whether they are (for Class X/Style 7 systems) the first modem (Head-End) or the last modem (Tail-End), or a modem between the first and last. For identification, "Generic" modem will be used for Class B connected modems and for those modems located within a Class X fiber loop and not functioning as the Head-End or Tail-End modem. Head-End Modem. For Class X communications, a "Head-End" modem is the first fiber optic modem in a fiber optic communications loop and is typically connected to the primary side of the communications channel in the head-end cabinet. A modem with wired connections to 4120 Network nodes or system transponders between itself and the head-end cabinet, is still considered to be the head-end modem if it is the first fiber optic modem in the communications path. Local Side. The "Local Side" of a wiring link has direct (non-isolated) electrical connection to the head-end cabinet. (terms are continued next page)

Product Selection (see page 8 for product dimensions except as noted)

4120 Network Fiber Modems for Internal Mounting in Fire Alarm Control Panels (Not ULC Listed)

Model	Fiber Type	Description		Application	
4100-6072	Single Mode	Left-Port Fiber Modem Assembly		For direct mounting onto a 4100ES/4100U expansion bay;	
4100-6074	Multi-Mode	Leit-FO	It Fibel Modelli Assembly	Fiber Modems are required to be ordered in pairs (Left-Port	
4100-6073	Single Mode	Right-Port Fiber Modem Assembly		Fiber Modems communicate only to Right-Port Fiber	
4100-6075	Multi-Mode	кіўні-г	on Fiber Modern Assembly	Modems)	
4100-9840	Single Fiber Modem Mounting Bracket; not required for 4100ES/4100U internal mounting; order Fiber Modems separately			Use for internal mounting in a 4100/4120 Series fire alarm control panel or in a compatible utility cabinet	
4100-9841	Audio Expansion Module Assembly, with mounting bracket			Use for internal mounting in a 4100/4120 Series fire alarm control panel; converts two analog audio input channels at	
4100-9842	Audio Expansi 4100-9841	on Modu	le only, mounts onto bracket of	25 VRMS or 70.7 VRMS to 10 VRMS for compatibility with the Fiber Modem Audio Input requirements; mounts next to Fiber Modem	
Expansion	ion Cabinet and Related Modem Assemblies for Remote Mounting				
Model		Description			
	Fiber Type	Descrip		Application	
4190-9021	Fiber Type Single Mode		otion		
4190-9021 4190-9024		Descrip Red		Application Cabinets mount external to compatible panels where internal mounting space is not available; typical applications are for	
	Single Mode Multi-Mode	Red	tion Expansion Cabinet with Left-Port Fiber Modem Assembly (see page 7 for	Cabinets mount external to compatible panels where internal mounting space is not available; typical applications are for 4010ES/4010 Fire Alarm Control Panels or 4100/4120 or	
4190-9024	Single Mode		tion Expansion Cabinet with Left-Port Fiber Modem	Cabinets mount external to compatible panels where internal mounting space is not available; typical applications are for	
4190-9024 4190-9022	Single Mode Multi-Mode Single Mode	Red Beige	tion Expansion Cabinet with Left-Port Fiber Modem Assembly (see page 7 for	Cabinets mount external to compatible panels where internal mounting space is not available; typical applications are for 4010ES/4010 Fire Alarm Control Panels or 4100/4120 or 4100ES/4100U cabinets without internal available space	
4190-9024 4190-9022 4190-9025	Single Mode Multi-Mode Single Mode Multi-Mode	Red Beige Right-P	tion Expansion Cabinet with Left-Port Fiber Modem Assembly (see page 7 for product details)	Cabinets mount external to compatible panels where internal mounting space is not available; typical applications are for 4010ES/4010 Fire Alarm Control Panels or 4100/4120 or	

Fiber Modem Terms (Continued)

Fiber Modem Operation Reference


NIC. Network Interface Card.

Remote Side. The "remote side" of a wiring link refers to wiring that is electrically isolated from the connections to the Head-End cabinet by passing through a Fiber Modem pair.


RIC. Riser Interface Card, typically located in a MINIPLEX transponder cabinet.

Tail-End Modem. A "Tail-End" modem is the **last** fiber optic modem in a Class X fiber optic communications loop and is typically connected to the secondary (return) side of the communications channel in the head-end cabinet. A modem with wired connections to 4120 Network nodes or system transponders between itself and the return connection, is still considered to be a tail-end modem if it is the **last** fiber optic modem in the communications path.

X-Link Connection. For Class X RUI communications or Class A Analog Audio Risers, these wired connections complete the primary-to-secondary supervision path. It provides a non-isolated electrical connection between the primary and secondary sides of the local-side wiring loop and connects between the Head-End and Tail-End modems or Audio Expansion Modules. In the event of a wiring fault, the Fiber Modems separate the x-link connection initiating Class X fiber optic communications. Digital Audio and 4120 Network communications do not require x-link connections. Note: X-Link wiring can be run external to the cabinets. (Refer to diagram on page 7.)



Fiber Optic Transmission Reference; Full Duplex/Bi-Directional Communications




Enhanced Analog Audio (EAA) connection maintains Riser 1 digital format; no need to convert back to digital for retransmission to next Fiber Modem


Application Reference 1, MINIPLEX Transponders

This diagram represents a 4100ES Emergency Voice/Alarm System with two, 4100ES MINIPLEX Transponders. Communications between the panel and the Transponders are Class X/Style 7 using a fiber loop. Communications include Remote Unit Interface (RUI), Analog Audio Riser 1 and Analog Riser 2. For detailed installation instructions and additional applications information, refer to document 579-831.

Note: RUI Communications are limited to up to eight (8) *modem pairs.*



Audio Expansion Module Reference




Notes:

- 1. A single Audio Expansion Module (4100-9841, with bracket) and a single internal mount Fiber Modem Assembly are required for Class B operation. (Audio Expansion Modules include harness that connects to the modem assembly.)
- 2. Class A connections require an additional Audio Expansion Module (4100-9842) and an additional Fiber Modem Assembly. For this application, X-Link connections (not shown) are made between Audio Expansion Modules, not at the Fiber Modems.
- 3. When mounted in a 4100/4120 cabinet, 4100-9840 Mounting Brackets are required for each Fiber Modem. (Audio Expansion Module model 4100-9841 includes a mounting bracket that accommodates two modules.) If internal space is not available, use Expansion Cabinets with options as required.


Fiber Modem Terminal Descriptions

тво т	orminal Docor	intion		_ TB1 T	erminal Description	1
Pos.	erminal Descr	Function		Pos.	Label	Function
		Network Left-Port		1	24V IN	Input power connections; also available at
1	INV –	terminals; input OR	18 1 0 0 0 0 0 0 0 0 0 0 0 0 0	2	24C IN	two separate on-board connectors for Fibe Modem use only
2	NON INV +	output depending on modem operation		3	RUI +	Remote Unit Interface (RUI) terminals; inpu
3	EARTH	Earth (ground)		4	RUI –	OR output depending on modem operation
3	LANTI	connection		5	RUI, XLINK +	RUI X-Link connections; wiring that connects between head-end and tail-end fo Class X/Style 7 fiber link systems
4	5C	5 VDC common (–) connection		6	RUI, XLINK –	
5	INV –	Network Right-Port		7	24C	Additional 24 VDC common and earth (ground) connection
Ũ	1110 -	terminals; input OR		8	EARTH	
6	NON INV +	output depending on modem operation		9	RISER 1 +	Analog Audio Riser 1 input OR output
7	EADTU	Earth (ground)		10	RISER 1 –	depending on modem operation
7	EARTH	connection	ø	11	RISER 1, XLINK +	Analog Audio Riser 1 X-Link connections;
8	0V ISO	Isolated common (–) 0 V connection	₩ 1 10	12	RISER 1, XLINK –	wiring that connects between head-end an tail-end for Class X fiber link systems
9	DAR –	Digital Audio Riser		13	24C	Additional 24 VDC common and earth (ground) connection
9	DAR -	terminals; input OR		14	EARTH	
10	DAR +	output depending on modem operation		15	RISER 2 +	Analog Audio Riser 2 input OR output
	1		· /	16	RISER 2 –	depending on modem operation
				17	RISER 2, XLINK +	Analog Audio Riser 2 X-Link connections; wiring that connects between head-end and
				18	RISER 2, XLINK –	tail-end for Class X fiber link systems

Application Reference 2, 4120 Network with Hub Node




X-Link Connection Reference Diagram



Notes:

- X-link connections are only required for Class X RUI and Class A Analog Audio Riser Fiber Modem applications.
- 2. It is recommended that Head-End and Tail-End Fiber Modems be located in the same cabinet.
- Loop devices with non-isolated supervision (MINIPLEX transponders, etc.) are allowed between Modems and Head-End Panel and on X-link wiring.
- X-link wiring can be extended between cabinets if required. Indoor wiring is recommended for system simplicity. Wiring between buildings must be equipped with proper suppression.

Remote Cabinet Mounting Reference



Voltage		18 to 33 VDC, from control p			
Current, Standby and Alarm		360 mA @ 24 VDC; with Analog Channels enabled			
		190 mA @ 24 VDC; without			
Analog Audio Riser Input and Output Levels			ndard); 1 Vp-p (0.35 VRMS); 0.707 VRMS		
Network Input Wiring		Optimized for 18 AWG (0.82	mm ²) or 24 AWG (0.2 mm ²)		
Audio Expansion Module	e Electrical Specific	ations			
Current		20 mA, Standby and Alarm			
Audio Input Voltage		25 VRMS or 70.7 VRMS			
Audio Output Voltage		10 VRMS			
Operation Reference		Each input is transformer iso	lated to output		
Fiber Optics Specificatio	ons				
General Notes Compatible Fiber Single-Mode					
	Multi-Mode				
Fiber Connector		Type ST			
	Single Mode Fiber	No limit			
Allowed Fiber Connections	Multi-Mode Fiber	Three (3) external connections maximum per link (does not include connectors on modems)			
Transmit and Receive	Left-Port Modems	Transmit = 1310 nm; Receive = 1550 nm	Launch power: -9.5dBm (112 µmW) +/- 10 µmW		
Wavelengths	Right-Port Modems	Transmit = 1550 nm; Receive = 1310 nm	Range: -9.91dBm (102 µmW) to 9.14dBm (122µmW)		
		Maximum total attenuation = 15 dB			
Transmission Distances for Sin (preferred fiber type) Note: These examples provide or greater; a 3 dB safety margin	a safety margin of 5 dB	Example 1 (low loss fiber): Assume fiber with attenuation of 0.34 db/km; a target distance of 35,000 ft (10.7 km) connector loss totaling 6 dB attenuation; calculate the safety margin: (10.7 km) x (0.34 db/km) = 3.68 dB fiber loss 15 dB - 3.68 dB - 6 dB = > 5 dB safety margin Example 2 (higher loss fiber): Assume fiberwise attenuities to 0.4 k/km a target distance of 25,000 ft (7.7 km)			
acceptable Transmission Distances for Mu	lti-Mode Fiber	Assume fiber with attenuation of 0.6 db/km; a target distance of 25,000 ft (7.7 km); and connector loss totaling 5 dB attenuation; calculate the safety margin: (7.7 km) x (0.6 db/km) = 4.62 dB fiber loss 15 dB - 4.62 dB - 5 dB = > 5 dB safety margin 5000 ft (1.6 km) maximum distance Maximum total attenuation = 6 dB			
Acceptance test require		50 µm or 62.5 µm GRIN (gra			

An initial acceptance test of each fiber link shall be performed in accordance with NFPA 72, Chapter 14 Inspection, Testing, and Maintenance (or other applicable local code) requirements. A fiber link is defined as all fiber segments, including patch cords, which create a fiber path from one fiber media board to another. Test result data must meet or exceed ANSI/TIA 568-C.3 (or newer) Optical Fiber Cabling Components Standard related to fiber optic lines and connection/splice losses and the manufacturer's published specifications.

OTDR launch and receive cables of appropriate length shall be used. If a single cable is used, each link shall be tested in both directions. 1.

Multi-mode fiber links shall be measured at 850 nm and 1300 nm. 2.

3. Single mode fiber links shall be measured at 1310 nm and 1550 nm.

Mounting/Enviro	onmental	Specifications		
4100ES/4100U Chassis Mounted			Two Vertical Block Module; 4" W x 11-5/16" H (102 mm x 287 mm)	
4100-9840 Mounting Bracket			4" W x 11-9/16" H x 0.064" Thick (102 mm x 294 mm x 1.6 mm)	
Remote Cabinets: 4190-9021, 4190-9022, 4190-9024, and 4190-9025		190-9022, 4190-9024,	14-5/8" W x 16" H x 4-1/4" D (372 mm x 483 mm x 108 mm); see page 7 for additional details	
4100-9842 Dual Transformer Audio Expansion Assembly		Mounting bracket	4" W x 11-1/2" H x 0.064" Thick (102 mm x 292 mm x 1.6 mm); mounts internal to 4100/4120 control panel	
		Module size	4" W x 3-5/8" H (102 mm x 91 mm)	
Environmental	Operating Temperature Range		32° to 120°F (0° to 49° C)	
Specifications	Operating Humidity Range		Up to 93% RH, non-condensing @ 100° F (38° C)	

Additional 4120 Network Product Reference

Subject	Data Sheet
4007ES Panels with Conventional Notification	S4007-0001
4007ES Panels with Addressable Notification	S4007-0002
4010ES Panels with Conventional Notification	S4010-0004
4010ES Panels with Conventional Notification (INTL)	S4010-0006
4010ES Panels with Addressable Notification	S4010-0011
4010ES Panels with Addressable Notification (INTL)	S4010-0012
4100ES Basic Panels with SPS Power Supplies	S4100-0031
NDU with SPS Power Supplies for 4120 Network	S4100-0036
InfoAlarm Command Center with SPS Power Supplies	S4100-0045
4120 Network Products and Specifications	S4100-0056
4100ES Basic Panels with EPS Power Supplies	S4100-0100
InfoAlarm Command Center with EPS Power Supplies	S4100-0101
NDU with EPS Power Supplies for 4120 Network	S4100-0102

TYCO, SIMPLEX, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited. NFPA 72 and National Fire Alarm Code are registered trademarks of the National Fire Protection Association (NFPA).

Simplex

Tyco Fire Protection Products • Westminster, MA • 01441-0001 • USA www.simplex-fire.com

© 2018 Tyco Fire Protection Products. All rights reserved. All specifications and other information shown were current as of document revision date and are subject to change without notice.